



QUICKfoam>5 the Ideal Solution

UMF | PerfectCLEAN has developed the **QUICKfoam>D** and **QUICKfoam>5** providing an ideal solution for foaming and disinfecting drains using the EPA registered KLORESE

disinfectant. In 2022 SHEA/APIC/IDSA introduced new guidelines for the disinfection of hand washing sink drains and P-traps to avoid contamination due to aerosolized pathogens from the drain line*. The guidelines recommend the use of a foaming disinfectant with EPA kill claims for bacteria in biofilm. The KLORESE hi-density foam formulation eliminates biofilm in drains and P-traps in minutes. For facilities looking to address a few drains at a time the economical, manual **QUICKfoam>D** is ideal.



QUICKfoam>D

For larger facilities the **QUICKfoam>5** provides a fast and efficient solution. In addition to addressing the pathogens in handwashing sinks, the **QUICKfoam>5** combination allows the end user to address floor drains and issues such as fruit flies that breed in the biofilms found in floor drains.

The spray attachment supplied with the **QUICKfoam** allows users to apply KLORESE as a foam on large areas, providing visual confirmation that surfaces have been disinfected and increasing contact times.



QUICKfoam>5



FLOORdrain foamer



SPRAYfoam

*⁶Glowicz et al Infection Control & Hospital Epidemiology (2023), 44, 355–376



Disinfecting Drains & P-traps **KloreSe™**

Make a 4,306 ppm **KloreSe™** disinfectant solution - add one 13.1 gram tablet to **QUICKfoam™** - fill to 32 oz mark



Allow tablet to completely dissolve before screwing on pump-head



- ⊕ Once tablet has dissolved screw on the pump-head and pump blue pump (A) handle (~ 10 X's) to pressurize.
- ⊕ Set **QUICKfoam** on counter
- ⊕ Place black drain-cap over drain and press firmly to seal
- ⊕ Depress trigger/button (B) to discharge KLORESE foam into drain until the **QUICKfoam** level reaches the 16 oz mark

DO NOT RINSE or RUN WATER in sink for a minimum of 4 minutes *or* leave KLORESE foam in drain until next use



Re-pressurize **QUICKfoam** as required and move on to the next sink.

For further information on cleaning & disinfecting processes using PerfectCLEAN products call

888 920 0370