



We put space to work.

Item # _____

Job _____

Starsys® Electronic PIN Lock

The Starsys PIN Lock is available for Starsys units with polymer drawers or Starsys units with hinged doors. This cost-effective security feature allows users to access the contents without worrying about losing or possessing traditional keys. It provides fast and easy access for up to 19 users and 1 supervisor using unique 4-8 digit codes. PIN lock is low maintenance with 5+ years battery life and hassle free with no software or feature programming making it simple to use and easy to maintain.

Benefits:

- **Convenience:** No need for users to carry a key
- **Easy to Use:** Input a valid user PIN, press ENTER, and just turn the lever to unlock.
- **Security:** User PINs are easily programmed to 4-8 digits
- **User Capacity:** Electronic locking to support up to 20 unique PINs (19 User, 1 Supervisor/Administrator)
- **Low Maintenance:**
 - 5+ years battery life
 - Runs on two AAA batteries
 - Easy-to-clean keypad
- **User friendly:**
 - Low battery indicator conveniently located relock latch

The Starsys PIN lock is available in two versions:

- **Self-locking** — features SlamCam, a spring loaded latch, which allows the user to simply close the cabinet door or drawer and it's locked. The lever must be held open when unlocking until the drawer or door is opened. Once released, the lever returns to the locked position.
- **Manual locking** — allows the user to unlock the unit and open and close drawers/door while the unit remains unlocked. To lock the unit, close the door or set of drawers, then, simply turn the lever to the locked position.



PIN Lock horizontal and vertical mounting.



PIN lock vertical mounting

All Metro Catalog Sheets are available on our website: www.metro.com



InterMetro Industries Corporation
North Washington Street, Wilkes-Barre, PA 18705
Product Information. U.S. and Canada: 1.800.992.1776
Outside U.S. and Canada: www.metro.com/contactus

LO2-240
Printed in U.S.A. Rev. 2/20

Information and specifications are subject to change without notice. Please confirm at time of order.

Copyright © 2020 InterMetro Industries Corp.



Starsys® Electronic PIN Lock

46-23

Job _____

Starsys® Electronic PIN Lock

The Starsys PIN lock is available for base cabinets, overhead cabinets, and carts with doors and/or drawers. All Starsys PIN Locks comes with a key override.

Short Door - Single

Cat. No.	Description	Orientation	Hinge Location
SXRXC LHSL	PIN Lock Kit, Self Locking, Left Hinge, Horizontal, for Short Single Door	Horizontal	Left
SXRXC LHSR	PIN Lock Kit, Self Locking, Right Hinge, Horizontal, for Short Single Door	Horizontal	Right

Short Door - Double, Center Closing

Cat. No.	Description	Orientation	Hinge Location
SXRXC LSCCBASE	PIN Lock Kit, Self Locking, Base, Double Door, Single Bay	Horizontal	Left/Right

Tall Door - Single *

Cat. No.	Description	Orientation	Hinge Location
SXRXC LVSL	PIN Lock Kit, Self Locking Left Hinge, Vertical, Tall Single Door	Vertical	Left
SXRXC LVSR	PIN Lock Kit, Self Locking, Right Hinge, Vertical, Tall Single Door	Vertical	Right

Tall Door - Double Center Closing**

Cat. No.	Description	Orientation	Hinge Location
SXRXC LSCC	PIN Lock Kit, Self Locking, Tall, Double Door, Single Bay	Vertical	Left/Right
SXRCDLOCK-D	PIN Lock Kit, Self Locking, Tall, XD Double Door, Single Bay	Vertical	Left/Right

Overhead Door - Single

Cat. No.	Description	Orientation	Hinge Location
SXRXC LOHSL	PIN Lock Kit, Self Locking, Left Hinge, for Single Door	Horizontal	Left
SXRXC LOHSR	PIN Lock Kit, Self Locking, Right Hinge, for Single Door	Horizontal	Right

Overhead Door - Double, Center Closing

Cat. No.	Description	Orientation	Hinge Location
SXRXC LSCCOH	PIN Lock Kit, Self Locking, Overhead, Double Door, Single Bay	Horizontal	Left/Right

Drawers - with Lock Module Above

Cat. No.	Description	Orientation	Hinge Location
SXRXC LDWR	PIN Lock Kit, Manual Locking, Bank of Drawers, Doors over Drawers	Horizontal	N/A

Short Door - Single

Cat. No.	Description	Orientation	Hinge Location
SXRXC LHML	PIN Lock Kit, Manual Locking, Left Hinge, Single Door	Horizontal	Left
SXRXC LHMR	PIN Lock Kit, Manual Locking, Right Hinge, Single Door	Horizontal	Right

Short Door - Double, Center Closing

Cat. No.	Description	Orientation	Hinge Location
SXRXC LMCCBASE	PIN Lock Kit, Manual Locking, Base, Double Door, Single Bay	Horizontal	Left/Right

Tall Door - Single*

Cat. No.	Description	Orientation	Hinge Location
SXRXC LVML	PIN Lock Kit, Manual Locking Left Hinge, Vertical, Tall Single Door	Vertical	Left
SXRXC LVMR	PIN Lock Kit, Manual Locking, Right Hinge, Vertical, Tall Single Door	Vertical	Right

Tall Door - Double, Center Closing**

Cat. No.	Description	Orientation	Hinge Location
SXRXC LMCC	PIN Lock Kit, Manual Locking, Tall, Double Door, Single Bay	Vertical	Left/Right
SXRCDLOCK-DML	PIN Lock Kit, Manual Locking, Tall, XD Double Door, Single Bay	Vertical	Left/Right

Overhead Door - Single

Cat. No.	Description	Orientation	Hinge Location
SXRXC LOHML	PIN Lock Kit, Manual Locking, Left Hinge, Single Door	Horizontal	Left
SXRXC LOHMR	PIN Lock Kit, Manual Locking, Right Hinge, Single Door	Horizontal	Right

Overhead Door - Double, Center Closing

Cat. No.	Description	Orientation	Hinge Location
SXRXC LMCCOH	PIN Lock Kit, Manual Locking, Overhead, Double Door, Single Bay	Horizontal	Left/Right

* PIN lock for tall single doors apply to standard and XD units.

** PIN lock for tall center closing doors have unique part numbers for standard and for XD units.

Self-Locking

Manual Locking

an Ali Group Company



The Spirit of Excellence