

TechNiGlove

INTERNATIONAL

PHYSICAL PROPERTIES

Style: STN1000W, STN2000B	Ambidextrous, Sterile
STN200P	Ambidextrous Pair Packed, Sterile
Length:	12" (300mm)
Thickness:	5 mil (.005")
Grip Surface:	Textured Fingertips
Cuff:	Beaded
Color: STN1000W, STN200P	White
STN2000B	Blue
Tensile Strength:	12.9 MPa minimum

TECHNICAL PROPERTIES

Particle Levels:	<2500 total particles/cm ² <0.5 µm
(Class 100)	IES RP-CC-005.2 Method
Electrical Properties Resistivity:	At 12.5% R. Humidity
	1x10 ² ohm/square per ESD-S11.12
Static Decay:	At 12.5% R. Humidity
	<3 seconds per RETS-5-003
Total Non Volatile Residue:	4.0 µg/cm ²
Sterilization Method:	Gamma Irradiation
Minimum Irradiation Dose:	25kGy
Sterility Accuracy Level:	10 ⁻⁶
Irradiation Dose Verification:	AAMI Method

Extractables

Silicone:	None	Sulfate (SO ₄ ²⁻):	<0.05 µg/cm ²
Amide:	None	Lithium (Li ⁺):	<0.005 µg/cm ²
Phthalates:	None	Sodium (Na ⁺):	<0.05 µg/cm ²
Fluoride (F ⁻):	<0.05 µg/cm ²	Ammonium (NH ₄ ⁺):	<0.05 µg/cm ²
Chloride (Cl ⁻):	<0.400 µg/cm ²	Potassium (K ⁺):	<0.05 µg/cm ²
Bromide (Br ⁻):	<0.05 µg/cm ²	Magnesium (Mg ²⁺):	<0.05 µg/cm ²
Nitrate (NO ₃ ⁻):	<2.00 µg/cm ²	Calcium (Ca ²⁺):	<0.05 µg/cm ²
Phosphate (PO ₄ ³⁻):	<0.05 µg/cm ²		

ORDERING INFORMATION

12" STERILE Class 10 Nitrile Gloves

WHITE - Pair Packed, Meets USP 797/800, Chemo Tested

Cat. No.

STN200P	X-SMALL	89415-116
STN201P	SMALL	89415-118
STN202P	MEDIUM	89415-120
STN203P	LARGE	89415-122
STN204P	X-LARGE	89415-124
STN205P	XX-LARGE	89415-126

1 Pair/Bag, 50 Pair/Master, 200 Pair/Case

WHITE - Bulk Packed

Cat. No.

STN1000W	X-SMALL	89415-128
STN1001W	SMALL	89415-130
STN1002W	MEDIUM	89415-132
STN1003W	LARGE	89415-134
STN1004W	X-LARGE	89415-136
STN1005W	XX-LARGE	89415-138

100 Gloves/Polybag, 10 Polybags/Case = 1,000 Gloves/Case

BLUE - Bulk Packed

Cat. No.

STN2000B	X-SMALL	89415-140
STN2001B	SMALL	89415-142
STN2002B	MEDIUM	89415-144
STN2003B	LARGE	89415-146
STN2004B	X-LARGE	89415-148

100 Gloves/Polybag, 10 Polybags/Case = 1,000 Gloves/Case



Permeation Test Results: TN1000W, XX-Large

Test Chemotherapy Drug and Concentration	Average Breakthrough Detection Time (Specimen 1/2/3) (Minutes)	Average Steady State Perm. Rate (Specimen 1/2/3) (µg/cm ² /minutes)
Fluorouracil, 50.0 mg/ml (50,000 ppm)	No breakthrough up to 240 min.	N/A
Eoposide (Toposar), 20.0 mg/ml (20,000 ppm)	No breakthrough up to 240 min.	N/A
Cyclophosphamide (Cytosan), 20.0 mg/ml (20,000 ppm)	No breakthrough up to 240 min.	N/A
Carmustine (BCNU) mg/ml (3,300 ppm)	36.13 (47.85, 55.87, 4.67)	0.15 (0.07, 0.28, 0.11)
Thiotepa, 10.0 mg/ml (10,000 ppm)	72.13 (69.43, 26.95, 120.0)	0.01 (0.01, 0.02, 0.01)
Paclitaxel (Taxol), 6.0 mg/ml (6,000 ppm)	No breakthrough up to 240 min.	N/A
Doxorubicin Hydrochloride, 2.0 mg/ml (2,000 ppm)	No breakthrough up to 240 min.	N/A
Dacarbazine (DTIC), 10.0 mg/ml (10,000 ppm)	No breakthrough up to 240 min.	N/A
Cisplatin, 1.0 mg/ml (1,000 ppm)	No breakthrough up to 240 min.	N/A

TechNiGlove
INTERNATIONAL

1220 Graphite Drive • Corona, CA 92881 • USA

Toll Free: 1-877-648-7453

Phone: 951-582-0890

Fax: 951-582-0990

www.techniglove.com